


AIMPUTT GUIDE

How to use your AimPutt

Two sides, two jobs. One side trains your start line. The other turns pace into a number. Here's how to set up each side, what the numbers mean, and the three drills that matter most.


■ The two sides



Start-line side

Trains a square face and a straight stroke.

Inch marks with a center line down the middle. The ball rolls along the bar on the center line; the line also shows your putter the path to follow.



Distance side

Turns pace into a number you can repeat.

Four dashed lines at one end, then distance marks in feet. Your backswing length decides how far the ball rolls.


■ What the numbers mean

Swing back to a number. The ball rolls about that far.

Each number on the distance side is a distance in feet. Take the putter face back to the **3'** mark and the ball rolls about 3 feet. Take it to **20'** and it rolls about 20 feet.

Always measure to the **putter face**, starting from the dashed lines. Keep the same rhythm and let the backswing length do the work.

On the start-line side the numbers are inches: use them to see how long your stroke is.



■ Setup

Start-line side

- 1 Lay the bar flat, start-line side up (inch marks and center line).
- 2 Point it straight at your target: a hole, tee or coin, 6 to 10 feet away.
- 3 Set the ball on the center line at the near end of the bar.
- 4 Roll it so it rides the center line the full length of the bar and off the far end.

Distance side

- 1 Flip the bar to the distance side and lay it along your target line, dashed end toward the target.
- 2 Set the ball just in front of the four dashed lines.
- 3 Rest your putter face on the dashed lines.
- 4 Take the putter back until the face reaches the mark for your distance, then stroke through.

The three drills that make you a better putter

Start line first, then pace. These train the two things that decide every putt.

1 The Start-Line Gate START-LINE SIDE

Start every putt exactly on your line.

Aim the bar at a target 6 to 10 feet away. Push two tees in just past the far end of the bar, a little wider than a ball apart.

- Ball on the center line at the near end.
- Roll it along the line, off the end and through the gate.
- Make 10 in a row. Miss once and restart the count.

WHAT IT TELLS YOU

Falls off the right side or clips the right tee: the face was open. Left: closed. (Right-handed golfer; flip it for lefties.) Rides the line and splits the gate: square face and path.

2 Calibrate Your Numbers DISTANCE SIDE

Learn how your stroke and your green match the marks.

Flat part of the green or your mat. Ball in front of the dashed lines, putter face on the dashed lines.

- Roll 3 balls with your backswing to the 10' mark. Pace off where they stop.
- Repeat at the 20' and 30' marks.
- Note the difference, e.g. "my 20' rolls about 23 feet here."

WHAT IT TELLS YOU

The marks are a starting point. Fast green? Go a little shorter than the number. Slow green or thick carpet? A little longer. Recheck on every new surface.

3 The Distance Ladder DISTANCE SIDE

Finish every lag close enough for an easy tap-in.

Set targets at 10, 20 and 30 feet. Picture a circle one putter-length wide around each.

- Backswing to 10', then 20', then 30'.
- Come back down: 30', 20', 10'.
- Any ball outside its circle: repeat that rung.

WHAT IT TELLS YOU

Only the backswing length changes; the rhythm stays the same. Count "one" back and "two" through, at every distance.

■ Your 15-minute routine

0–2 min	Calibration check: 2 balls at the 20' mark.
2–7 min	Start-Line Gate: 10 in a row.
7–14 min	Distance Ladder: 10' → 20' → 30' and back.
14–15 min	5 more through the gate. Leave on a make.


■ Watch it



Start line
Video



Distance
Video



Full guide
Online